



# COOK Extended Mounting Flange

DATE: \_\_\_\_\_

PROJECT: \_\_\_\_\_

LOCATION: \_\_\_\_\_

SWB, SWD, AWB, AWD, HWB, EWB  
 XLW, XMW, XLWH, XMWH  
 XLP, XMP, XLPH, XMPH  
 APD, APB, SPD, SPB  
 Propeller Wall Fans

## DIMENSION DATA

SWD,SWB,HWB AWD,AWB,XLW XMW,XLWH,XMWH XLP,XMP,XLPH,XMPH APD,APB,SPD,SPB Size	EWB Size	A Sq.	B Sq.	C Sq.	D	E	WO*	Galvanized Steel Gauge
8	-	12-1/8	21	10	12	16	12-7/8	14
10	-	16-3/16	25	14	14-3/8	18-3/4	17	14
12	-	16-3/16	25	14	14-3/8	18-3/4	17	14
14	-	20-3/16	29	18	15-3/8	21-3/4	21	14
16	-	20-3/16	29	18	15-3/8	21-3/4	21	14
18	-	24-3/16	33	22	17-5/8	24-1/2	25	14
20	-	24-3/16	33	22	17-5/8	24-1/2	25	12
24	-	30-3/16	37	28	18-3/4	27-1/4	31	12
30	24	36-3/16	43	34	18-3/4	31-1/2	37	12
36	30	42-3/16	49	40	19-1/2	35-3/4	43	12
42	36	48-3/16	55	46	19-1/2	40	49	12
48	42	54-3/16	61	52	19-3/4	44-1/4	55	12
54	48	60-3/16	67	58	19-3/4	48-1/2	61	12
60	54	66-3/16	73	64	19-3/4	52-3/4	67	12
-	60	72-3/16	79	70	19-3/4	57	73	12
-	72	84-3/16	91	82	19-3/4	67-7/16	85	12

ALL DIMENSIONS IN INCHES.

\* THE WO (WALL OPENING) DIMENSION IS TO THE OUTSIDE OF THE FASTENERS.

\* FASTENERS SHOULD BE PLACED ON 6" TO 10" CENTERS ON THE PERIMETER OF THE WALL COLLAR. WALL COLLAR SHOULD BE CAULKED TO THE EXTERIOR OF THE WALL.

NOTE: ALLOWS MOUNTING OF WEATHER HOOD TO WALL COLLAR OR WALL HOUSING.

